

Solar inverter

USER GUIDE

Solar Inverter
IVBM Series(8KVA~10KVA)



Contents

1. About This Manual	1
1.1 Purpose.....	1
1.2 Scope.....	1
1.3 Safety Instructions.....	1
2. Warning Marks	2
3. Introductions	3
3.1 Features.....	3
3.2 Basic system architecture.....	3
4. Product Overview	4
5. Specifications	5
6. Installation	8
6.1 Safety guidance.....	8
6.2 Unpacking and inspection.....	8
6.3 Mounting the inverter.....	9
6.4 Battery connection.....	10
6.5 AC input /output connection.....	11
6.6 PV connection.....	14
6.7 Final assembly.....	15
6.8 Dry contact signal.....	16
6.9 Inverter and computer connection.....	16
6.10 Wiring system for inverter.....	17
7. Operation	18
7.1 Power ON/OFF.....	18
7.2 Operation and display panel.....	18
7.3 LCD display icons.....	19
7.4 LCD operation flow chart.....	21
7.5 Base information page.....	22
7.6 Setting page.....	24
7.7 BMS information page.....	31
7.8 Rated information page.....	32
7.9 Generator port use setup page.....	32
7.10 Lithium battery communication.....	33

8. Parallel Installation Guide	35
8.1 Introduction.....	35
8.2 Mounting the inverter.....	35
9. LCD Setting and Display	38
9.1 Commissioning.....	38
10.Warning Code Table	40
11.Fault Code Table	40
12.The Wi-Fi Operation Guide in APP	44
12.1 Introduction.....	44
12.2 Download and install APP.....	44

1. About This Manual

1.1 Purpose

This manual describes the assembly, installation, operation, warning code and fault code of this inverter. Please read this manual carefully before installations and operations. Keep this manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

1.3 Safety Instructions



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION**-Please pay attention to safety when using batteries.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** – Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. Fuse is provided as over-current protection for the battery supply.
11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please contact local dealer or service center for maintenance.

2. Warning Marks

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

Mark	Name	Instruction	Abbreviation
 Danger	Danger	Serious physical injury or even death may occur if not follow relevant requirements.	
 Warning	Warning	Physical injury or damage to the device may occur if not follow relevant requirements.	
 Forbid	Electrostatic sensitive	Damage may occur if relevant requirements are not followed.	
 Hot	High temperature	Do not touch the base of the inverter as it will become hot.	
Note	Note	The procedures taken for ensuring proper operation.	Note

3. Introduction

This is a multi-function inverter/charger, combining functions of inverter, MPPT solar charge controller and battery charger to offer uninterrupted power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

3.1 Features

- Pure sine wave inverter
- Built-in MPPT solar charge controller (Supports 2 strings of solar input)
- Built-in Wi-Fi for mobile monitoring (APP is required and can be download via QR code following the manual)
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Control smart output port can customize output duration. An intelligent load is a load management device with intelligent timing control and battery protection functions. It can set functions such as start time, duration, when the battery capacity is left, and when the battery voltage drops below.
- Overload / Over temperature/ short circuit protection
- Inverter running without battery
- Lithium battery activation function
- Cold start function
- Parallel connection quantity up to 6units(Battery must be connected).
- Auto restart while AC is recovering


3.2 Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:


- Generator or Utility.
- PV modules (option)

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.



4. Product Overview



- | | | |
|------------------------------|--------------------------------|-----------------------------|
| 1.LCD display | 11.Communication port | 21.Current sharing port |
| 2.Charging indicator | 12.WIFI | 22.RS232 communication port |
| 3.Utility bypass indicator | 13.PV connection port | 23.CAN communication port |
| 4.Inverter indicator | 14.LOAD interface | 24.RS485 communication port |
| 5.Fault or warning indicator | 15.GEN interface | 25.Dry contact |
| 6.ESC button | 16.GRID interface | 26.Input breaker |
| 7.UP button | 17.PE | 27.Wall-mounted accessory |
| 8.DOWN button | 18.BAT+ | 28.Power ON/OFF |
| 9.ENTER button | 19.BAT- | |
| 10.Communication port | 20.Parallel communication port | |

5. Specifications

Line Mode Specifications		
Model	IVBM8048P1G1	IVBM10048P1G1
Rated Output Power	8000VA	10000VA
	8000W	10000W
Nominal DC Input Voltage	48V	
Input Voltage Waveform	Sinusoidal (utility or generator)	
Nominal Input Voltage	230Vac	
Low Line Voltage Disconnect	170Vac±7V (UPS); 90Vac±7V (Appliances)	
Low Loss Voltage Re-connect	180Vac±7V (UPS); 100Vac±7V (Appliances)	
High Line Voltage Disconnect	280Vac±7V	
High Line Voltage Re-connect	270Vac±7V	
Max AC Input Voltage	280Vac	
Nominal Input Frequency	50Hz / 60Hz (Auto detection)	
Low Line Frequency Disconnect	40±1Hz	
Low Line Frequency Re-connect	42±1Hz	
High Line Frequency Disconnect	65±1Hz	
High Line Frequency Re-connect	63±1Hz	
Output Voltage Waveform	As same as input waveform	
Output Short Circuit Protection	Line mode: Circuit Breaker Battery mode: Electronic Circuits	
Efficiency (Line Mode)	>95% (Rated R load, battery full charged)	
Transfer Time (Single unit)	10ms typical (UPS); 20ms typical (Appliances)	
Pass Through Without Battery	Yes	
Output power derating: When AC input voltage drops to 180V, the output power will be de-rated.		
Max. Bypass Overload Current	53A/8000W	65A/10000W
Max. Inverter/Rectifier Current	40A/8000W	46A/10600W
Max. Smart Load Output Current	40A	46A
Max. Input Current of Generator	32A	

Utility Charging Mode Specifications / Generator Charging Mode Specifications		
Nominal Input Voltage	230Vac	
Input Voltage Range	90-280Vac	
Nominal Output Voltage	Dependent on battery type	
Max. Charging Current of Grid	150A	200A
Max. Charging Current of Generator	100A	
Charge Current Regulation	10-150A(Adjustable unit is 1A)	
Over Charge Protection	Yes	
Solar Charging & Grid Charging or GEN Charging		
Max. PV Open Circuit Voltage	500V	
PV Voltage Working Range	90V-450V	
Max. Input Power	10000W(5000W for single PV)	11000W(5500W for single PV)
Max. Solar Charging Current	150A	200A
Max. Charging Current(PV+Grid or GEN)	150A	200A
Max. PV Input Current	20A×2(MAX 40A)	
Min. Startup Voltage	160V	

Charge Algorithm			
Algorithm	Three stage: Boost CC (Constant current stage) -> Boost CV (Constant voltage stage) -> Float (Constant voltage stage)		
Charging Curve			
Battery Type Setting	Battery Type	Boost CC/CV	Float
	AGM	56.4V	54V
	Flooded	58.4V	54V
	Self - defined	Adjustable, up to 60V	
	Lithium		

Inverter Mode Specifications		
Model	IVBM8048P1G1	IVBM10048P1G1
Rated Output Power	8000VA	10000VA
	8000W	10000W
Nominal DC Input Voltage	48V	
Output Voltage Waveform	Pure sine wave	
Nominal Output Voltage	230Vac±5%	
Nominal Output Frequency (Hz)	50±0.3Hz/60Hz±0.3Hz (Adjustable)	
Peak Efficiency	94.5%	
Over-Load Protection (SMPS load)	5s@ ≥150% load; 10s@105%~150%load	
Surge Rating	2* rated power for 5s	
Capable of Starting Electric	Yes	
Output Short Circuit Protection	Yes	
Cold Start Voltage	46V	
Low Battery Alarm Load < 50% @Load ≥ 50%	45.0V	44.0V
	47.0V	46.0V
Low Battery Alarm Recovery Load < 50% @Load ≥ 50%	43.0V	42.0V
	43.0V	42.0V
High DC Input Alarm & Fault	60V±0.4V	
High DC Input Recovery	56.4V±0.4V	
General Specifications		
Operating Temperature	0°C~50°C	
Range Storage Temperature	-15°C~60°C	
Net Weight (Kg)	24.3kg	
Gross Weight(Kg)	28.3kg	
Product Size (D*W*H)	525x490x189.2mm	
Package Dimension (D*W*H)	597x572x267mm	

6. Installation



6.1 Safety Guidance

Warning marks inform users of conditions which can cause serious physical injury or death, or damage to the device. They also tell users how to prevent the dangers. The warning marks used in this operation manual are shown below:

	<ul style="list-style-type: none"> After receiving this product, first confirm the product package is intact. If any question, contact the logistic company or local distributor immediately. The installation and operation of inverter must be carried out by professional technicians who have received professional trainings and thoroughly familiar with all the contents in this manual and the safety requirements of the electrical system.
	<ul style="list-style-type: none"> Do not carry out connection/disconnection, unpacking inspection and unit replacement operations on the inverter when power source is applied. Before wiring and inspection, users must confirm the breakers on DC and AC side of inverter are disconnected and wait for at least 5 minutes.
	<ul style="list-style-type: none"> Ensure there is no strong electromagnetic interference caused by other electronic or electrical devices around the installation site. Do not refit the inverter unless authorized. All the electrical installation must conform to local and national electrical standards
	<ul style="list-style-type: none"> Do not touch the housing of the inverter or the radiator to avoid scald as they may become hot during operation.
	<ul style="list-style-type: none"> Ground with proper technics before operation.
	<ul style="list-style-type: none"> Do not open the surface cover of the inverter unless authorized. The electronic components inside the inverter are electrostatic sensitive. Do take proper anti-electrostatic measures during authorized operation.
	<ul style="list-style-type: none"> The inverter needs to be reliably grounded.
	<ul style="list-style-type: none"> Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking.

6.2 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:


			
Inverter x 1	User Manual x 1	Parallel Manual x 1	Battery terminal x 2
			
OT terminal x 4	Current sharing cable x 1	Parallel communication cable x 1	RJ45 Terminal x 1



6.3 Mounting the Inverter


Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a vertical wall with load-bearing capacity, suitable for installation concrete or other non-flammable surfaces
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature should be between 0°C and 50°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.




SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Step 1. When installing the inverter, please use the recommended size and M10 drill bit to drill 4 holes at the correct position, with a depth of 45-50mm. Insert the expansion bolt into the hole with a suitable hammer, and then unscrew the nut of the expansion bolt.



Step 2. Please take out the crank iron from the package and lock it onto the inverter with the M5 combination screw. Install the inverter into the expansion screw and tighten the expansion nut that comes with the expansion screw (after tightening the expansion nut, make sure the inverter is firmly fixed to the wall). Note that the inverter is very heavy.



6.4 Battery Connection

CAUTION: For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.

Recommended battery cable and terminal size:



Model	Cable	Connection terminal
8KVA	70mm ²	SC50-8
10KVA	95mm ²	SC50-8

Please follow below steps to implement battery connection:

Assemble the battery ring terminals according to the recommended battery cable and terminal sizes.

1. Connect all battery packs as required by the unit. It is recommended to connect a battery with a capacity of at least 200Ah.
2. After crimping the terminals, please use a heat shrink sleeve with a temperature resistance exceeding 100°C or insulating tape for wrapping treatment.
3. Insert the circular terminal of the battery cable flat into the battery connector of the inverter and make sure the screws are tightened.
4. Tighten with a torque of 12Nm. Make sure the polarity of the battery and inverter/charger is correctly connected and the ring terminal is securely fastened to the battery terminal.

BAT+ → Red
BAT- → Black



Connect the positive and negative battery wires to the following positions and tighten the screws

+ M8
⌚ 12N.m



WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

CAUTION! Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

CAUTION! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) and negative (-) must be connected to positive (+) and negative (-) must be connected to negative (-).

6.5 AC Input/Output Connection



CAUTION! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 63A for 8KVA model, 80A for 10KVA model.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires

Model	Gauge	Cable (mm ²)
8KVA	8 AWG	10
10KVA	6AWG	16

Please follow the steps below to achieve AC input/output connection:

1. Before making an AC input/output connection, please be sure to turn off all DC input.
2. Remove the 10mm insulating sleeves of the conductors and correctly connect them to the inverter according to the markings inside the inverter box.

3. Generator interface operation

The generator interface has two multiplexing modes: generator input (GEN) and smart load output (SLD). The default is GEN mode. If you want to switch to SLD mode, refer to the "LCD Settings" section for details.

Insert AC output / AC input wires according to polarities indicated on terminal block and tighten terminal screws.


Make sure to connect the PE (⊕) protective conductor of the chassis first.



→ Ground (yellow-green)

L → LINE (brown or black)



N → Neutral (blue)



Strip the wire according to its size and organize the wire core properly.



Insert the terminals into the terminal heads of the corresponding chassis according to the cable terminal instructions and tighten the screws.



4. GRID interface operation


Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Make sure to connect the PE (⊕) protective conductor of the chassis first.




→ Ground (yellow-green)

L → LINE (brown or black)



N → Neutral (blue)



Strip the wire according to its size and organize the wire core properly



Insert the terminals into the terminal heads of the corresponding chassis according to the cable terminal instructions and tighten the screws




WARNING!

1. Be sure that AC power source is disconnected before attempting to hardwire it to the unit.
2. When locking the terminals, please ensure that GRID and GEN are respectively connected to the corresponding terminals. Do not connect them wrongly!


5. LOAD interface operation

Insert AC output wires according to polarities indicated on terminal block and tighten terminal screws
Make sure to connect the PE (⊕) protective conductor of the chassis first.


- ⊕ → **Ground (yellow-green)**
- L → **LINE (brown or black)**
- N → **Neutral (blue)**



Strip the wire according to its size and organize the wire core properly



Insert the terminals into the terminal heads of the corresponding chassis according to the cable terminal instructions and tighten the screws



6. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

6.6 PV Connection

CAUTION: Before connecting to PV modules, please install separately a 600VDC/30A circuit breaker between inverter and PV modules.

WARNING! All wiring must be performed by qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Cable Size	Cable (mm ²)
8KVA	10~12AWG	4~6
10KVA	10AWG	6

PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

- The total value of open circuit Voltage (Voc) in one PV module string not exceeds to the max PV array open circuit voltage of inverter.
- Max. power voltage (Vmp) should be during PV array MPPT voltage range.

Solar Charging Mode	
INVERTER MODEL	8KVA/10KVA
Max. PV Array Open Circuit Voltage	450V
PV Array MPPT Voltage Range	100Vdc~450Vdc

Please follow below steps to implement PV module connection:

Step 1: Check the input voltage of PV array modules. This system is applied with two strings of PV array. Please make sure that the current load of each PV input connector is less than 18A.


CAUTION: Exceeding the maximum input voltage can destroy the unit!! Check the system before wire connection.


Step 2: Disconnect the AC circuit breaker and switch off the DC switch

Step 3: Assemble provided PV connectors with PV modules by the following steps..

Please strip the cables to the dimensions shown in the following picture with professional tools before installation.


- PV+ → **Red**
- PV- → **Black**





6.7 Final Assembly

After connecting all wirings, please put bottom cover back by screwing eight screws as shown below.




6.8 Dry Contact Signal

There is one dry contact (3A/250VAC) available on the inverter.

Unit Status	Condition	Dry contact port:	
		NC & C	NO & C
Power Off	Unit is off and no output is powered.	Close	Open
Power On	Battery voltage < Setting value in Program 12	Open	Close
	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage	Close	Open

6.9 Inverter and Computer Connection




Pin Assignment for RS232 Communication Port

	PIN 1	PIN 2	PIN 3	PIN 4	PIN 5	PIN 6	PIN 7	PIN 8	
RS232	RS232TX	RS232RX	+12V	GND	NC	NC	NC	GND	

*Users need to purchase their own RS232 conversion USB interface cable to connect the computer
 *If you need to update the firmware library, please contact after-sales personnel

6.10 Wiring System for Inverter



NOTE 1: Before starting up inverters, please connect all N wires of AC output together
NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire

7. Operation

7.1 Power ON/OFF

1. Power On: Once the unit has been correctly installed and the battery is well connected, just press the on/off switch (Located on the left side of the inverter) and hear the buzzer remind the drop sound, you can release the switch and the machine will start normally
2. Power Off: If you continue to press the switch, the machine will turn off the machine after the buzzer reminds the drop sound.



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (Located on the left side of the inverter) to turn on the unit.

7.2 Operation and Display Panel


The operation and display panel, shown in below chart, is on the front panel of the inverter. it includes four indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



Function Key	Icon	Description
ESC		To previous page
UP		To go to previous selection
DOWN		To go to next selection
ENTER		To confirm the selection or go to next page

LED Indicator	Icon	Description
Battery		Charging the battery, the LED light flash. If battery is full, the LED light will always-on. The battery is not charged, the LED light will go out.
Utility		Inverter running in utility mode, the LED will always-on. Inverter is not running in utility mode, the LED will go out.
Inverter		Inverter running in off-grid mode, the LED light will always-on. Inverter is not running in off-grid mode, the LED light will go out.
Fault		If inverter in fault event, the LED light will always-on. If inverter in warning event, the LED light will flash. Inverter work normally, the LED light will go out.
Buzzer Information		
Buzzer beep		Turn on/off the inverter, The buzzer will keep ringing until you release the button. Press any button, the buzzer will last for 0.1s. Hold on the "ENTER" button, the buzzer will last for 3s. If in fault event, the buzzer will keep going. If in warning event, the buzzer will beep discontinuous (Check more information on the chapter of "Warning Code Table").


7.3 LCD Display Icons



Icon	Function description
Input Source Information	
	Indicate input voltage, input frequency, PV voltage, PV power, battery voltage and charger current, GEN port.
Configuration Program and Fault Information	
	Indicates the setting programs.
	Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code

Output Information	
	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.
Battery Information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100%.
	Indicates Lithium battery type.
	Indicates communication is built between inverter and battery.
Mode Operation Information	
	Indicates the utility.
	Indicates load is supplied by utility directly.
	Indicates the inverter/charger is working.
	Indicates the PV panels.
	Indicates PV MPPT is working.
	Indicates the WIFI link
	Indicates the AC output
	Indicates the smart load output
	Indicates the generator input
PV1 PV2	Which PV is lit indicates that it is working
Mute Operation	
	Indicates unit alarm is disabled.

7.4 LCD Operation Flow Chart














On base information page, pressing and holding "ENTER" key for 3 sec, the unit will enter parameters page. Press "UP" or "DOWN" key to switch the selection and press "ENTER" key to enter selected page. Press "ESC" key to back to previous page.

7.5 Base Information Page

The base information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Input voltage / Output voltage Utility voltage is 230V, output voltage is 230V</p>	<p>Input frequency / Output voltage Utility frequency is 50.0Hz, output voltage is 230V</p>
<p>Battery voltage / Output voltage Battery voltage is 50.0V, output voltage is 230V</p>	<p>Charging current / Output voltage Charging current is 10A, output voltage is 230V</p>
<p>PV1 voltage PV1 voltage is 360V</p>	<p>PV2 voltage PV2 voltage is 360V</p>
<p>PV1 power PV1 power is 3.00kW</p>	<p>PV2 power PV2 power is 3.00kW</p>


<p>Battery voltage / Output frequency Battery voltage is 50.0V, output frequency is 50.0Hz</p> 	<p>Battery voltage / Load percentage Battery voltage is 50.0V, load percentage is 40%</p> 
<p>Battery voltage / Load VA 1. Battery voltage is 50.0V, output wattage is 2.00kVA</p> 	<p>Battery voltage / Load wattage Battery voltage is 50.0V output wattage is 2.00kW</p> 
<p>Battery voltage / Discharging current Battery voltage is 50.0V, discharging current is 80A</p> 	<p>Generator voltage/generator power Indicates the generator input 230V, input 2KW power</p> 
<p>Generator frequency/Generator current Indicates that the generator input frequency is 60Hz and the inpu current is 8.7A</p> 	<p>Smart load Voltage / Smart load power Indicates that the smart load output 230V, output 2KW power</p> 

<p>Smart load frequency/Smart load current Indicates that the Smart load output frequency is 60Hz and the output current is 8.7A</p> 	<p>Date 2022-01-01</p> 
<p>Time 09:58:55</p> 	

7.6 Setting Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Setting items:

No	Item	Slectable Option	Remark
00	Exit setting		
01	Output voltage setting	<p>220V </p> <p>230V (Default) </p> <p>240V </p>	Output voltage configuration
02	Output frequency setting	<p>50Hz (Default) </p> <p>60Hz </p>	Output frequency configuration

03	Utility input range setting	Appliance mode (Default) AC [03] APL	APL should be selected, when the utility is not well. When the mains power is normal, the UPS mode supplies power to the load and charges the battery through the inverter. When there is a power outage, it seamlessly switches to battery power supply. Appliance mode supports wide voltage input from mains power (such as 90-280V).
		UPS mode AC [03] UPS	
04	Output source priority	Utility or GEN >> PV >> Battery (Default) OPS [04] USB	Utility or generator provides power to the loads first, PV and battery will provide power to loads only when utility is not available. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV >> Utility or GEN >> Battery OPS [04] SUB	PV provides power to the loads first. If PV is not sufficient, utility or generator will supply power the loads at the same time. Battery will provide power to loads only when utility is not available. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV >> Battery >> Utility or GEN OPS [04] SUB	PV provides power to the loads first. If PV is not sufficient, battery will supply power to the loads at the same time. Utility or generator provides power to the loads only when battery voltage drops to the setting point in program 12. Tip: When utility and generator exist at the same time, utility charging is preferred
05	Charger priority	If inverter is working in utility mode, charger priority can be set as below. However, when inverter is working in Battery mode, only PV can charge battery. Utility mode is directly powered by mains electricity and supports both mains power supply and charging battery mode is completely dependent on battery power supply	
		PV first (Default) CHS [05] C50	The PV will charge the battery first. Only when PV is not available will the utility or generator charge the battery. Tip: When utility and generator exist at the same time, utility charging is preferred
		PV and Utility or GEN CHS [05] SNU	PV and utility or generator will charge battery together. Tip: When utility and generator exist at the same time, utility charging is preferred
	PV Only CHS [05] 050	Only PV can charge the battery.	

06	Max charging current (Utility charge current + PV charging current)	60A (Default) bCC [06] 60 ^A	Setting range is from 10A to 150A. Increment of each click is 1A.
07	Max utility charging current setting	30A (Default) CHC [07] 30 ^A	Setting range is from 10A to 150A. Increment of each click is 1A.
08	Battery type setting	The battery type is AGM (Default) bAt [08] AGM	If "Self-defined" or "Lib" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 9, 10 and 11. If "Lib" is selected, inverter can charge Lithium battery when the Lithium battery need to be activated. Please make sure Lithium battery is connected before you start up inverter. If inverter doesn't connect battery or Lithium battery, do not select "Lib" battery type.
		The battery type is Flooded bAt [08] FLD	
		The battery type is self-defined bAt [08] USE	
		The battery type is Lib bAt [08] LIB	
09	Bulk charging voltage setting (C.V voltage)	Default : 56.4V C ^V [09] 56.4 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 48.0V to 60V. Increment of each click is 0.1V
10	Floating charging voltage	Default : 54.0V FL ^V [10] 54.0 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 48.0V to 60.0V. Increment of each click is 0.1V
11	Low DC cut-off voltage or Low SOC	If battery power is only power source available, inverter will shut down. If PV energy and battery power are available, inverter will charge battery without AC output. If PV energy, battery power and utility are all available, inverter will transfer to line mode and provide output power to loads.	
		Default : 42.0V bC ^V [11] 42.0 ^V	If "self-defined" is selected in program 8, this program is enabled. Setting range is from 42.0V to 54.0V. Increment of each click is 0.1V
		SOC 0% (default for Lithium) bC ^V [11] 0 [%]	If or "Lib" is selected in program 8, this program is enabled. Setting range is from 0% to 90%. Increment of each click is 5%.

12	Setting battery voltage point back to utility when selecting "SBU priority" in program 4	Default : 46.0V bUv [12] 46.0 ^v	Setting range is from 44.0V to 54.0V. Increment of each click is 0.1V
		SOC.10% (default for Lithium) bUv [12] 10 ^s	Setting range is from 5% to 95%. Increment of each click is 5%.
13	Setting battery voltage point back to battery mode when selecting "SBU priority" in program 4	Fully charged bbv [13] FUL	Battery should be charged to float charging stage.
		Default : 54V bbv [13] 54.0 ^v	Setting range is from 48.0V to 60.0V. Increment of each click is 0.1V
		SOC 30% (default for Lithium) bbv [13] 30 ^s	Setting range is from 10% to 100%. Increment of each click is 5%.
14	Overload bypass function	Disable (Default) LbP [14] d15	If it is enabled, the inverter will switch to utility mode if overload happens in battery mode.
		Enable LbP [14] ENA	
15	Overload restart function	Disable (Default) OLr [15] d15	If it is enabled, the inverter will auto restart when overload occurs.
		Enable OLr [15] ENA	
16	Over temperature restart function	Disable (Default) Otr [16] d15	If it is enabled, the inverter will auto restart when over temperature occurs.
		Enable Otr [16] ENA	
17	Backlight of LCD	Disable bL [17] d15	If selected, LCD backlight will be off after no button is pressed for 60s.
		Enable (Default) bL [17] ENA	If selected, LCD backlight will be always-on.

18	Auto return to the first page of display screen	Disable bFP [18] d15	If selected, the display screen will stay at latest screen user finally switches.
		Enable (Default) bFP [18] ENA	If selected, it will automatically return to the first page of display screen (Input voltage/ output voltage) after no button is pressed for 60s.
19	Buzzer Alarm	Disable bEP [19] d15	If selected, buzzer is not allowed to beep.
		Enable (Default) bEP [19] ENA	If selected, buzzer is allowed to beep.
21	Energy stored data for PV and Load	Disable ESd [21] d15	If selected, inverter will release all historical data of PV and Load energy, and stop record historical data for PV and Load energy.
		Enable (Default) ESd [21] ENA	If selected, inverter will record historical data for PV and Load energy. NOTE: Before selected, please double check if date and time is correct, if incorrect, please set date and time in program 22~27.
Items 22 to 27 set world time			
22	Time setting- Year	Year yEA [22] 22	Setting range is from 22 to 99.
23	Time setting- Month	Month mON [23] 1	Setting range is from 1 to 12
24	Time setting- Day	Day dAY [24] 1	Setting range is from 1 to 31
25	Time setting- Hour	Hour HOu [25] 9	Setting range is from 0 to 23
26	Time setting- Minute	Minute n IN [26] 58	Setting range is from 0 to 59

27	Time setting- Second	Second SEC [27] 30	Setting range is from 0 to 59
28	AC output mode	Single [28] S1C	When the inverter are used in parallel with single phase, please select "PAL" in program 28
		Parallel [28] PAL	It is required to have at least 3 inverters or maximum six inverters to support three-phase equipment.
		L1 Phase [28] 3P1	It's required to have at least one inverter in each phase or it's up to four inverters in one phase.
		L2 Phase [28] 3P2	Please select "3P1" in program 28 for the inverters connected to L1 phase, "3P2" in program 28 for the inverters connected to L2 phase and "3P3" in program 28 for the inverters connected to L3 phase.
		L3 Phase [28] 3P3	DO NOT connect share current cable between inverters on different phases. Before starting up inverters, please connect all N wires of AC output together.
Item 29 to 32 Sets the the smart load output interval. If the setting range is from 00:00 to 08:59, the smart load output will be turned on until 09:00. During this period, if the set value in item 34 or 35/36 is triggered, it will be turned off. (If the 34 time Settings work for 30 minutes, then 00:31, the smart load output is off)			
29	Start time setting-Hour	Default : 0 hour StH [29] 0	Setting rage is from 0 to 23.Increment of each click is 1 hour.
30	Start time setting-Minute	Default : 0 minute Stn [30] 0	Setting rage is from 0 to 59.Increment of each click is 1 minute.
31	End time setting-Hour	Default : 0 hour EnH [31] 0	Setting rage is from 0 to 23.Increment of each click is 1 hour.
32	End time setting-Minute	Default : 0 minute Enn [32] 0	Setting rage is from 0 to 59.Increment of each click is 1 minute.

33	Setting discharge time on the smart load output if "Single" is selected in program 28.	Disable (Default) tln [33] dis	Setting range is from 0 min to 990 min. Increment of each click is 5 minute. This item is disabled by default. 'dis' indicates disabled *If the battery discharge time achieves the setting time in program 30,31,32 and 33 and the program 35 or 36 function is not triggered, the output will be turned off.
34	Setting cut-off voltage point on the smart load output if "Single" is selected in program 28.	Default : 54V nlv [34] 54.0v	If "User-defined" is selected in program 08, this setting range is from 42.0V to 54.0V for 48V model. Increment of each click is 0.1V.
35	Setting SOC percentage on the smart load output if "Single" is selected in program 28.	Default : 60% nls [35] 60%	If "Lib" is selected in program 08, this parameter value will be displayed in percentage and value setting is based on battery capacity percentage. Setting range is from 0% to 95%. Increment of each click is 5%.

7.7 BMS information Page

The BMS information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Mean SOC/ Battery pack number / BMS status Mean SOC is 97%, Connected Battery pack number is 4, BMS status is 51 (Check detail in warning code table). If BMS status occurred, it will be rolled with battery pack number automatically.</p>	
<p>BMS version / SOC BMS version is 100, SOC is 99% on battery pack of address 1</p>	<p>BMS voltage / current BMS voltage is 54.0V, current is 1A on battery pack of address 1</p>
<p>BMS highest temperature / lowest temperature BMS highest temperature is 25°C, lowest temperature is -10°C on battery pack of address 1</p>	<p>BMS fault code / flag BMS fault code is 0, flag is 000 on battery pack of address 1</p>

7.8 Rated information Page

The rated information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Rated VA / WATT Rated VA is 8KVA, WATT is 8KW</p>	<p>Rated battery voltage / Max. charge current Rated battery voltage is 48V, Max. charge current is 150A</p>
<p>Firmware version Firmware version is 2104</p>	

7.9 Generator Port Use Setup Page

Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

Setting items:


No	Item	Selectable Option	Remark
00	Exit setting	00 ESC	
01	AC input priority	POT 01 GEN	"GEN" stands for Generator Priority Mode, "SLD" stands for Grid Priority Mode.
		POT 01 SLD	

02	Generator charging enable	Disable (Default) CHG 02 d15	This option is used by default, if you choose not to use, the generator cannot be charged
		CHG 02 ENA	
03	Generator charging power setting	1 PL 03 080 KW	Press the "ENTER" key each time to select the value to change; Use the "UP" key to decrease the value and the "DOWN" key to increase the value The maximum setting value is 8KW and the minimum setting value is 0.5KW Default value is 5KW

7.10 Lithium Battery Communication

It's allowed to connect lithium battery and build communication only which it has been configured. Please follow below steps to configure communication between lithium battery and inverter.

1. Connect power cables between lithium battery and inverter. Please pay attention to the terminals of positive and negative. Make sure the positive terminal of battery is connected to the positive terminal of inverter, and the negative terminal of battery is connected to the negative terminal of inverter.
2. The communication cable is connected with lithium battery. Both sides are RJ45 port. One port is connected to the BMS(RS485) port of inverter and another one is connected to the COM port of lithium battery.
3. This is a normal when hearing the buzzer sound for 2-3 seconds while inverter and lithium battery are establishing communication.



Pin Assignment for CAN/RS485 Communication Port


	CAN	RS485	
PIN 1	NC	COM-GND	
PIN 2	NC	NC	
PIN 3	NC	CAN.L	
PIN 4	CAN.H	CAN.H	
PIN 5	CAN.L	RS485-B	
PIN 6	COM-GND	RS485-A	
PIN 7	RS485-A	NC	
PIN 8	RS485-B	NC	

Note: That the use of lithium mode should ensure that the inverter and battery pack communication is normal


3. Configure battery type to "Lib" in LCD setting No. 08.

The battery type is Lib
bat 08 Lib


And then LCD will show you "Li" icon.



4. Power up lithium battery and inverter. Wait a moment, if the communication is built between them, LCD will show you "C" icon as below.



5. Roll LCD real time information pages by pressing "UP" or "DOWN" button, as below page, you can see the parameters of SOC and battery pack units in the communication system.



This page means SOC is 88% and battery pack units are 8.

8. Parallel Installation Guide

8.1 Introduction

This inverter can be used in parallel with two different operation modes


1. Parallel operation in single phase with up to 6 units. The supported maximum output power is 48KW/48KVA.
2. Maximum six units work together to support three-phase equipment. Four units support one phase maximum. The supported maximum output power is 48KW/48KVA and one phase can be up to 32KW/32KVA.

NOTE 1: If this inverter is bundled with share current cable and parallel cable, this inverter is default supported parallel operation. You may skip section 2.

NOTE 2: Under parallel operation modes, battery must be connected with inverters.

NOTE 3: Before starting up inverters, please connect all N wires of AC output together.


8.2 Mounting the Inverter



NOTE:

- For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit. Be sure to install each unit in the same level.
- The areas above, below, to the left, and to the right must remain blank and cannot hold any other items.
- It is recommended that the parallel gap be 20cm. If the parallel gap is larger than 20cm, consult the technical personnel of the manufacturer

Single Phase Parallel connection diagram for three inverters




NOTE 1: Before starting up inverters, please connect all N wires of AC output together

NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire

NOTE 3: Before starting up inverters, please connect all negative (-) wires of battery together.

Three Phase Parallel connection diagram for three inverters



- NOTE 1: Before starting up inverters, please connect all N wires of AC output together
- NOTE 2: Do not connect the AC input Neutral (N) wire to the AC output Neutral (N) wire
- NOTE 3: Before starting up inverters, please connect all negative (-) wires of battery together.

9. LCD Setting and Display

9.1 Commissioning

Parallel in single phase


Step 1: Check the following requirements before commissioning:

- Correct wire connection.
- The input and output switches of the inverter are disconnected. All output neutral wires are connected together, and all input neutral wires are connected together. The input neutral wires and output neutral wires are not connected.

Step 2: Turn on each unit and set "PAL" in LCD setting program 28 of each unit. And then shut down all units.


NOTE: To be safe, it's better to turn off switch when setting LCD program (Output circuit breakers: mains power and generator circuit breakers are off. Set LCD program to battery or PV start mode).

Step 3: Turn on each unit.



NOTE: Master and slave units are randomly defined.

Step 4: Switch on all AC breakers of Line wires in AC input. It's better to have all inverters connect to utility at the same time.



Step 5: If there is no more fault alarm, the parallel system is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Parallel in three phase




Step 1: Check the following requirements before commissioning:

- Correct wire connection
- The input and output switches of the inverter are disconnected. All output neutral wires are connected together, and all input neutral wires are connected together. The input neutral wires and output neutral wires are not connected.




Step 2: Turn on all units and configure LCD program 28 as P1, P2 and P3 sequentially. And then shut down all units.

NOTE: To be safe, it's better to turn off switch when setting LCD program (Output circuit breakers: mains power and generator circuit breakers are off. Set LCD program to battery or PV start mode).

Step 3: Turn on all units sequentially.

LCD display in L1-phase unit	LCD display in L2-phase unit	LCD display in L3-phase unit
		

Step 4: Switch on all AC breakers of Line wires in AC input. If AC connection is detected and three phases are matched with unit setting, they will work normally. Otherwise, the AC icon  will flash and they will not work in line mode.

LCD display in L1-phase unit	LCD display in L2-phase unit	LCD display in L3-phase unit
		

Step 5: If there is no more fault alarm, the system to support 3-phase equipment is completely installed.

Step 6: Please switch on all breakers of Line wires in load side. This system will start to provide power to the load.

Note 1: To avoid overload occurring, before turning on breakers in load side, it's better to have whole system in operation first.

Note 2: Transfer time for this operation exists. Power interruption may happen to critical devices, which cannot bear transfer time.

10. Warning Code Table

When fault event happens, the fault LED is flashing. At the same time, warning code, icon  is shown on the LCD screen.

Warning Code	Warning Information	Audible Alarm	Trouble Shooting
01	Fan is locked.	Beep three times every second	Check if the Fans wiring connected well. Replace the fan.
02	Overload	Beep twice every second	Reduce the loads.
03	Low battery	Beep once every second	The battery voltage is too low, it should be charging.
04	Grid anomaly	Grid icon blinking	Check whether the input is overvoltage or overfrequency
05	Three-phase input missing phase	Fault LED flashing	Check whether the three-phase mains input is normal
06	The three-phase parallel is abnormal	Fault LED flashing	Verify that the three-phase communication is normal
07	Generator anomaly	Generator icon blinking	Check whether the input is overvoltage or overfrequency
08	Three-phase parallel generator input phase deficiency	Fault LED flashing	Check whether the three-phase mains input is normal
50	BMS firmware version is not matched.		Upgrade the firmware of BMS.
51	BMS doesn't allow inverter to charge battery.		Inverter will stop charging battery automatically.
52	BMS doesn't allow inverter to discharge battery.		Inverter will stop discharging battery automatically.
53	BMS require inverter to charge battery.		Inverter will charge battery automatically.
54~65	BMS detect something wrong happened.		If the code is keeping for long time, please contact with your installer.
80	The BMS communication is abnormal	Beep once every second	Check whether the BMS communication cable is connected

11. Fault Code Table

When fault event happens, inverter will cut off output, and the fault LED is solid on. At the same time, fault code, icon  and **ERROR** are shown on the LCD screen.

Fault Code	Fault information	Trouble Shooting
01	Bus voltage is too high	AC Surge or internal components failed. Restart the unit, if the error happens again, please return to repair center.

02	Bus voltage is too low	Restart the unit, if the error happens again, please return to repair center.
03	Bus soft start fail	Internal components failed. Restart the unit, if the error happens again, please return to repair center.
04	Inverter soft start fail	1.Internal components failed Restart the unit, if the error happens again, please return to repair center. 2.Check if the output is short circuited
05	Over current or surge detected by Software	Restart the unit, if the error happens again, please return to repair center.
06	Over current or surge detected by hardware	Restart the unit, if the error happens again, please return to repair center.
07	Output voltage is too low	Reduce the connected load. Restart the unit, if the error happens again, please return to repair center.
08	Output voltage is too high	Restart the unit, if the error happens again, please return to repair center.
09	Output short circuited	Check if wiring is connected well and remove abnormal load.
10	Overload time out	Reduce the connected load by switching off some equipment.
11	Battery voltage is too high	Check if spec and quantity of batteries are meet requirements.
12	Over current happen at DC/DC circuit	Restart the unit, if the error happens again, please return to repair center.
13	PV voltage is too high	Reduce the number of PV modules in series.
14	Short circuited happen at PV port	Check if wiring is connected well.
15	PV power is abnormal	Reduce the number of PV modules.
16	Over current happen at PV port	Restart the unit, if the error happens again, please return to repair center.
17	Fan is locked	Check if wiring is connected well. Replace the fan.
18	Over temperature happen at PV circuit	The temperature of internal PV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
19	Over temperature happen at Convert L circuit	The temperature of Convert L battery converter component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
20	Over temperature happen at INV circuit	The temperature of internal INV component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.

21	The inner temperature over	The inner temperature is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
22	DCDC current sensor failed	Restart the unit, if the error happens again, please return to repair center.
23	No.2 DCDC current sensor failed	Restart the unit, if the error happens again, please return to repair center.
24	Inverter current sensor failed	Restart the unit, if the error happens again, please return to repair center.
25	OP current sensor failed	Restart the unit, if the error happens again, please return to repair center.
26	Sharing current sensor failed	Restart the unit, if the error happens again, please return to repair center.
27	The AC input and output wires are inversely connected	1. Please check AC input and output wires are connected correctly. 2. If this error happens during parallel installation, please check wires connection. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer.
28	Single unit is installed to parallel system	1. Please check if single unit is installed to parallel system. 2. If this error happens during parallel installation, please check wires connectioin. If they are connected correctly, please finish parallel installation first, and then restart inverters. 3. If the problem remains, please contact your installer.
29	DC/DC soft start fail.	Restart the unit, if the error happens again, please return to repair center.
31	Over temperature happen at convert H circuit	The temperature of internal convert H component is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
32	Over temperature happen at LLC TX	The temperature of internal DC/DC TX is over the limitation. Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
33	Over current happen at LLC circuit	Restart the unit, if the error happens again, please return to repair center
34	DC/DC hardware overflows	Restart the unit, if the error happens again, please return to repair center.
35	Overvoltage occurs in BUS	1.AC surge or PV surge or internal components failed. 2.Restart the unit, if the error happens again, please return to repair center.
40	CAN data loss	1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer.
41	Host data loss	
42	Synchronization data loss	


43	Current feedback into the inverter is detected.	<ol style="list-style-type: none"> 1. Restart the inverter. 2. Check if L/N cables are not connected reversely in all inverters. 3. For parallel system in single phase, make sure the sharing cables are connected in all inverters. For supporting three-phase system, make sure the sharing cables are connected in the inverters in the same phase, and disconnected in the inverters in different phases. 4. If the problem remains, please contact your installer.
44	The firmware version of each inverter is not the same.	<ol style="list-style-type: none"> 1. Update all inverter firmware to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are same. If not, please contact your installer to provide the firmware to update. 3. After updating, if the problem still remains, please contact your installer.
45	The output current of each inverter is different.	<ol style="list-style-type: none"> 1. Check if sharing cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer.
46	AC output mode setting is different.	<ol style="list-style-type: none"> 1. Switch off the inverter and check LCD setting program 28. 2. For parallel system in single phase, make sure no 3P1, 3P2 or 3P3 is set on program 28. For supporting three-phase system, make sure no "PAL" is set on program 28. 3. If the problem remains, please contact your installer.
47	Generator current sensor failed	Restart the unit, if the error happens again, please return to repair center.

12. The Wi-Fi operation Guide in APP

12.1 Introduction

Wireless communication between the off-grid inverter and the APP can be realized through the Wi-Fi module. The APP supports Android and iOS devices.

Delivers device status during normal operation.
Allows device Settings to be configured on the APP.
Notifies users when a warning or alarm occurs.
Allows users to query inverter history data.



The status of the Wi-Fi sign on the LCD display
After the APP is successfully connected, Wi-Fi indicator light remains constantly on

12.2 Download and install APP

Operating system requirement for your smart phone:

- 🍏 iOS system supports iOS 11.0 and above
- 🤖 Android system supports Android 5.0 above

APP Download
Please scan the following QR code with your smartphone to download the App.



The QR code supports Android system and iOS system

Operation Manual
Please scan the following QR code with your smartphone to view the App Operation Manual



The QR code supports Android system and iOS system